



NTUA theater
 Basic light plot
 ETC 54-19
 ETC 54-2G
 ETC 54-3G
 FRESNEL
 CYC

Hanging Plot

No	Batten	Operation Method	Distance to Previous Batten (cm)	Distance to PL (cm)
0	Fire Curtain	Electric	-	18
1	Border 1 (Teaser)	Manual	0	49.5
2	Leg 1 (Tormentor)	Manual	38	87.5
3	Main Curtain	Computer	20	107.5
4	Scenery Batten	Manual	20	127.5
5	1st Lighting Batten (E1)	Electric	20	147.5
6	Scenery Batten	Computer	20	167.5
7	Scenery Batten	Manual	20	187.5
8	1st Reflector Panel (A1)	Electric	35	222.5
9	Border 2	Computer	30	252.5
10	Leg 2	Manual	20	272.5
11	Scenery Batten	Manual	20	292.5
12	Scenery Batten	Manual	20	312.5
13	2nd Lighting Batten (E2)	Electric	30	342.5
14	White Scrim	Computer	43.5	386
15	Scenery Batten	Manual	18	404
16	Border 3	Manual	20	424
17	Leg 3	Manual	20	444
18	3rd Lighting Batten (E3)	Electric	35	479
19	2nd Reflector Panel (A2)	Electric	33	512
20	Scenery Batten	Manual	36	548
21	Scenery Batten	Computer	20	568
22	Scenery Batten	Manual	20	588
23	Scenery Batten	Computer	20	608
24	Border 4	Manual	20	628
25	Leg 4	Computer	20	648
26	4th Lighting Batten (E4)	Electric	40	688
27	Scenery Batten	Manual	20	708
28	Scenery Batten	Manual	20	728
29	Middle Curtain	Computer	20	748
30	Scenery Batten	Manual	20	768
31	Scenery Batten	Manual	20	788
32	Border 5	Computer	25	813
33	Leg 5	Manual	20	833
34	Scenery Batten	Manual	20	853
35	5th Lighting Batten (E5)	Electric	25	878
36	Scenery Batten	Computer	20	898
37	Scenery Batten	Manual	20	918
38	Scenery Batten	Computer	20	938
39	Scenery Batten	Manual	20	958
40	Border 6	Computer	20	978
41	Leg 6	Manual	20	998
42	6th Lighting Batten (E6)	Electric	30	1028
43	Scenery Batten	Manual	64	1092
44	Scenery Batten	Computer	20	1112
45	Scenery Batten	Manual	20	1132
46	Projection Screen	Computer	20	1152
47	Scenery Batten	Manual	20	1172
48	Black Scrim	Computer	20	1192
49	Scenery Batten	Manual	20	1212
50	Backdrop Curtain	Computer	20	1232
51	Cyclorama	Manual	20	1252